

NVIDIA Jetson Nano Setup

Setup Headless Jetson with GUI Client

Harley's Tutorial for different client side DMs

We use **X2Go**.

https://teawiki.net/doku.php?id=workshops:nvidia_jetson:xavier_nx:start

Changing Runlevel

Change the Jetson runlevel to non-GUI to switch off the gnome display manager (or other DM) to free memory.

Instead enable graphical login with [X2Go](#).

```
# Temporary
sudo systemctl isolate multi-user.target

# Permanent
sudo systemctl set-default multi-user.target
```

ROS Setup

https://teawiki.net/doku.php?id=workshops:nvidia_jetson:xavier_nx:ros_setup

From:
<https://wiki.eolab.de/> - **HSRW EOLab Wiki**

Permanent link:
<https://wiki.eolab.de/doku.php?id=projects:jetson:nano:start&rev=1686403644>

Last update: **2023/06/10 15:27**

