

RUT956 Config

- LAN
 - IPv4 address: 192.168.200.1
 - IPv4 netmask: 255.255.255.0
- DHCP
 - Start: 192.168.200.100
 - End: 192.168.200.249
 - Lease: 12h
- APN auto

VPN

- Mit PiVPN Profil erstellt [WICHTIG nopass Option]
- Services → VPN → OpenVPN
 - Enable OpenVPN config from file

From:
<https://wiki.eolab.de/> - **HSRW EOLab Wiki**

Permanent link:
<https://wiki.eolab.de/doku.php?id=eolab:dieter:router-config&rev=1732010746>

Last update: **2024/11/19 11:05**

