

# RUT956 Config

- LAN
  - IPv4 address: 192.168.200.1
  - IPv4 netmask: 255.255.255.0
- DHCP
  - Start: 192.168.200.100
  - End: 192.168.200.249
  - Lease: 12h
- APN auto

## VPN

- Mit PiVPN Profil erstellt [WICHTIG nopass Option]
- Services → VPN → OpenVPN
  - Enable OpenVPN config from file

From:

<https://wiki.eolab.de/> - HSRW EOLab Wiki

Permanent link:

<https://wiki.eolab.de/doku.php?id=eolab:dieter:router-neuhoffnung-config&rev=1732011585>

Last update: **2024/11/19 11:19**

