

# SDK Manager

- SDK Manager Image available on FOG Server
  - IoTLAB Network <http://10.180.12.3>
  - Can be installed on any old IoTLab PC
- Currently installed Version 1.9.1
- Maybe you need to login with your own NVIDIA Account, maybe someone is still logged in from last time
- To install Image on Orin:
  - Connect USB C Cable to lonely USB C Port besides the 40-pin header
  - Connect power while holding the middle button besides the power button (force recovery mode)
  - Go through all the steps in th SDK Manager
  - Everything is explained there

## Important Links:

- [NVIDIA Jetson Orin How To](#)
- [SDK Manager General Tutorial](#)

From:  
<https://wiki.eolab.de/> - **HSRW EOLab Wiki**

Permanent link:  
[https://wiki.eolab.de/doku.php?id=projects:jetson:orin:sdk\\_manager:start](https://wiki.eolab.de/doku.php?id=projects:jetson:orin:sdk_manager:start)

Last update: **2023/03/13 14:16**

