

# Rolf Becker (rolf001) - Public Page

These pages are meant to be my personal scratch books, for arbitrary notes.

## RASA NLU

I want to use [RASA](#) as a ChatBot to fill forms.

## vosk ASR

Automatic Speech Recognition (ASR) with [vosk](#)

## Hackday Moers 2023

### Caspers Data API

- <https://opendata.dasdigidings.de/>

### TTN Appllication Moers Umwelt

- <https://eu1.cloud.thethings.network/console/>
- User ro
- <https://eu1.cloud.thethings.network/console/applications/moers-umwelt>

## Node-RED

<https://nodered.org/docs/getting-started/raspberrypi>

### ### ADDITIONAL RECOMMENDATIONS ###

- Remove the `/etc/sudoers.d/010_pi-nopasswd` file to require entering your password

when performing any `sudo/root` commands:

```
sudo rm -f /etc/sudoers.d/010_pi-nopasswd
```

- You can customise the initial settings by running:

```
node-red admin init
```

- After running Node-RED for the first time, change the ownership of the settings

file to 'root' to prevent unauthorised changes:

```
sudo chown root:root ~/.node-red/settings.js
```

```
sudo systemctl enable nodered.service
```


```
sudo systemctl start nodered.service
```

## Password auf Node-RED setzen

## Web Frontend

- <http://192.168.1.117:1880/>
- <http://rollo.local:1880/>

## InfluxDB

- <https://www.influxdata.com/>
- <https://docs.influxdata.com/influxdb/v2.6/get-started/>
- <https://docs.influxdata.com/influxdb/v1.8/introduction/download/>
-  <https://docs.influxdata.com/influxdb/v1.8/introduction/install/?t=curl>

```
cd ~
```

```
# influxdata-archive_compat.key GPG Fingerprint:
9D539D90D3328DC7D6C8D3B9D8FF8E1F7DF8B07E
curl -s https://repos.influxdata.com/influxdata-archive_compat.key >
influxdata-archive_compat.key
echo '393e8779c89ac8d958f81f942f9ad7fb82a25e133faddaf92e15b16e6ac9ce4c
influxdata-archive_compat.key' | sha256sum -c && cat influxdata-
archive_compat.key | gpg --dearmor | sudo tee
/etc/apt/trusted.gpg.d/influxdata-archive_compat.gpg > /dev/null
echo 'deb [signed-by=/etc/apt/trusted.gpg.d/influxdata-archive_compat.gpg]
https://repos.influxdata.com/debian stable main' | sudo tee
/etc/apt/sources.list.d/influxdata.list
```

```
ls -al
```

```
sudo apt-get update && sudo apt-get install influxdb
sudo systemctl unmask influxdb.service
sudo systemctl start influxdb
```

- [https://docs.influxdata.com/influxdb/v1.8/administration/authentication\\_and\\_authorization/](https://docs.influxdata.com/influxdb/v1.8/administration/authentication_and_authorization/)
- [https://docs.influxdata.com/influxdb/v1.8/administration/authentication\\_and\\_authorization/#user-management-commands](https://docs.influxdata.com/influxdb/v1.8/administration/authentication_and_authorization/#user-management-commands)

```
influx
```

```
CREATE USER admin WITH PASSWORD '<password>' WITH ALL PRIVILEGES
```

```
exit
```

```
# drop user admin
```

```
sudo vi /etc/influxdb/influxdb.conf
```

```
# Determines whether user authentication is enabled over HTTP/HTTPS.  
auth-enabled = true
```

```
sudo systemctl restart influxdb.service
```

```
influx
```

```
create database sensordaten
```

```
# Port 8086
```

## Grafana

<https://grafana.com/tutorials/install-grafana-on-raspberry-pi/>

```
wget -q -O - https://packages.grafana.com/gpg.key | sudo apt-key add -  
echo "deb https://packages.grafana.com/oss/deb stable main" | sudo tee -a  
/etc/apt/sources.list.d/grafana.list
```

```
sudo apt-get update
```

```
sudo apt-get install -y grafana
```

```
systemctl enable grafana-server  
# Port 3000
```

## Royal Eijkelkamp

[Meeting 2022-02-09](#)

---

My [private](#) page.

From:

<https://wiki.eolab.de/> - **HSRW EOLab Wiki**

Permanent link:

<https://wiki.eolab.de/doku.php?id=user:rolf001>

Last update: **2023/09/22 09:22**

