

# Finding Rzero

[Finding\\_Rzero.ino](#)

```
#include "MQ135.h"
const int ANALOGPIN=A0;
MQ135 gasSensor = MQ135(ANALOGPIN);
void setup(){
  Serial.begin(9600);      // sets the serial port to 9600
}
void loop(){
  float rzero = gasSensor.getRZero();
  Serial.println(rzero);
  delay(1000);
}
```

From:  
<https://wiki.eolab.de/> - **HSRW EOLab Wiki**

Permanent link:  
<https://wiki.eolab.de/doku.php?id=amc2021:group1:extras:r0:start&rev=1630798608>

Last update: **2021/09/05 01:36**

