

# Arduino Code

## For Carbon Dioxide detection in air

This code communicates with the MQ135 air quality sensor. The sensor is supposed to preheat for 24 hours before taking readings. Once the code runs, it prints out the concentration of detected gases in ppm on a serial monitor and the results are displayed on an LCD screen. An alarm system (LED light) is also set to glow if the CO<sub>2</sub> values cross a threshold value of 1000ppm.

```
#include [[amc2021:group1:extras:MQ-135|"MQ135.h"]]
#include <Wire.h>
#include <LiquidCrystal_I2C.h> //Header file for LCD

LiquidCrystal_I2C lcd(0x27,16,2); //set the LCD address to x27 for a 16 chars
and 2 line display

#define led          9                //led on pin 9
const int gas_pin = A0;              //analog feed from MQ135
MQ135 gasSensor = MQ135(gas_pin);

void setup(){

  lcd.init();                        // initialize the lcd
  lcd.begin(16,2);                   // consider 16 chars + 2 lines lcd
  lcd.backlight();                   // illuminate to produce visible reading
  lcd.clear();                        // clear lcd
  lcd.setCursor(4,0);                //set cursor of lcd to 1st row and 5th
column
  lcd.print("Group L");              // print as a sentence on lcd

  pinMode(gas_pin,INPUT);            //MQ135 analog feed set for input
  pinMode(led,OUTPUT);               //led set for output
  Serial.begin(9600);                //serial comms for debugging
}

void loop(){
  float ppm = gasSensor.getPPM();
  Serial.println(ppm);               // print ppm on serial monitor
  delay(1000);
  lcd.clear();                       // clear lcd
  lcd.setCursor(0,0);                // set cursor of lcd to 1st row and 1st
column
  lcd.print("Air Quality: ");        // print as a sentence on lcd
  lcd.print(ppm);                    // print value of MQ135
  if(ppm>999){                       //if co2 ppm > 1000
    digitalWrite(led,HIGH);          //turn on led
    lcd.setCursor(2,1);              // set cursor of lcd to 2nd row and 3rd
column
```

```

    lcd.print("AQ Level BAD"); //print as a sentence on lcd
  }
  else{
    digitalWrite(led,LOW);          //turn off led
    lcd.setCursor(1,1);            // set cursor of lcd to 2nd row and 2nd
column
    lcd.print ("AQ Level Good");    // print as a sentence on lcd
  }
}
}

```

## For noise disturbance detection in the environment

```

/* This code is meant to monitor the sound intensity using LM393 sensor
connected to Arduino UNO board.
//The used sensor has only a digital output. Therefore, the number of times
the sensor detects a sound is summed up over a sampling time called
"SAMPLE_TIME".
//Then the sum called "sampleBufferValue" is printed on a Serial Monitor
(laptop), and visualized with the Serial Plotter.
// The code allows to communicate with a LED in order to provide a visual
alarm if the "sampleBufferValue" surpasses a preset Threshold "Threshold"
*/

// 0 means silence and 1 means noise

const int OUT_PIN = 12;          // The OUTPUT of the sound sensor is
connected to the digital pin D12 of the Arduino
const int SAMPLE_TIME = 10;     // The sampling time in milliseconds, can
be set differently if required
const int Threshold = 90;       // Threshold on decibel value for LED
switching ON, the value has been optimized with respect to the used sampling
time (900 cumulative digital counts ≈ 90 dB from "Schall")

unsigned long millisCurrent;     // current time
unsigned long millisLast = 0;    //previous time
unsigned long millisElapsed = 0; // difference between current time and
previous time (time interval)

int sampleBufferValue = 0;       // initiate the sum of digital outputs
over the sampling time
int led = 8;                     // LED on pin 4 of Arduino
int dB = 0;                      //initiate sound intensity dB value

void setup() {

  Serial.begin(9600);            //Arduino starts serial communication with
baud rate 9600
  pinMode(led,OUTPUT);          // the LED is connected as output for alarm

```

```
purpose
}

void loop() {

    millisCurrent = millis();           //the current time is
assigned to the dedicated variable
    millisElapsed = millisCurrent - millisLast; //the elapsed time is updated
    if(digitalRead(OUT_PIN) == HIGH){    //HIGH means noise
        sampleBufferValue++;           //increments the sum variable
by 1
    }
    if (millisElapsed > SAMPLE_TIME) {  //if the elapsed time surpasses
the sampling time, print the sampleBufferValue and test threshold for alarm
        dB = 0.0666 *(sampleBufferValue) + 30.223; //linear regression to
calculate the decibel value based of the rough calibration of the sensor
response
        Serial.println(dB);           // print decibel values on the
Serial Monitor
        Serial.print("dB");           // print sound unit decibel
        if (sampleBufferValue > Threshold) { // test if the threshold is
surpassed
            digitalWrite(led, HIGH);  //blink LED 2 ms ON and 1 ms OFF
            delay(2);
            digitalWrite(led, LOW);
            delay(1);
        }
        digitalWrite(led, LOW);       // the LED is turned off to be
ready for the next sample
        sampleBufferValue = 0;        // re-initialization of the
sampleBufferValue variable for the new sampling time
        millisLast = millisCurrent;   // update the previous time to be
the start for the next sample
    }
}
```

From:

<https://wiki.eolab.de/> - **HSRW EOLab Wiki**

Permanent link:

<https://wiki.eolab.de/doku.php?id=amc2021:group1:code:start&rev=1630625878>

Last update: **2021/09/03 01:37**

