

# Introduction to IoT

Welcome to Day 1 of our IoT Workshop! Today, we introduced the basics of IoT through presentations and hands-on activities, covering topics from setting up your development environment to hardware essentials and simple programming.

## 1. IoT Intro Presentation

## 2. Setup Development Environment

- [VS Code](#).
- Install Platformio extensions
- (in some cases) Install the missing USB Driver for the [CP210x USB to UART Bridge](#)

## 3. Hardware Review

- [AMC Core Kit by EOLab](#)
- [Breadboard Overview](#)

## 5. Coding Warm-up

Now let's check if your Microcontroller works. Also, you will learn how to upload your first sketch. Basic Blink example:

[main.cpp](#)

```
#include "Arduino.h"

void setup() {
  // initialize digital pin LED_BUILTIN as an output.
  pinMode(LED_BUILTIN, OUTPUT);
}

// the loop function runs over and over again forever
void loop() {
  digitalWrite(LED_BUILTIN, HIGH); // turn the LED on (HIGH is the
  voltage level)
  delay(1000); // wait for a second
  digitalWrite(LED_BUILTIN, LOW); // turn the LED off by making the
  voltage LOW
  delay(1000); // wait for a second
```

}

From:

<https://wiki.eolab.de/> - **HSRW EOLab Wiki**

Permanent link:

<https://wiki.eolab.de/doku.php?id=inhabitat:kaunas:day01>

Last update: **2026/05/26 08:10**

